




## ECU Harness Connecting Piece



ECU (ECU harnesses and ECU connecting pieces)



ECU/A (ECU harnesses and instrument harness connecting pieces)



ECU/B (ECU harnesses and engine compartment harness connecting pieces)